



Uniden Dect 6.0 Battery Replacement

This guide will help a Uniden Dect 6.0 home phone owner replace the battery pack.

Written By: Mary



INTRODUCTION

This guide explains the simplest and quickest way to to replace the faulty batteries on the back of the Uniden home phone!



PARTS:

- [Uniden Replacement Battery](#) (1)
-

Step 1 — Battery




- Locate the battery compartment on the back of the Uniden home phone.
- Place your finger on groove, and pull directly back on the cover to gain access to the battery.

Step 2



- Remove the white battery pack from the battery compartment.

Step 3



- Remove the red and black wired port from the plug in located directly under the battery compartment.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-12 05:39:19 PM.